











Code : 22051 & 22052




⚠ Warning Warning - Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, ie if a child attempts to climb up on the furniture or in the event of an earthquake. Accordingly, we recommend that all furniture is anchored to a wall. We supply a free safety wall anchor with all furniture sold and we recommend these are used to prevent your product tipping. See our blog here for more info on using wall anchors.




	A 4pcs
	B 25pcs
	C 2pcs
	D 4pcs
	E 4pcs
	F 1pcs
	

1




B*1

2




B*8

3




B*8

4




B*8

5




F*4

7




6




D*4

8



A*4



C*2 F*1