

TOUGH OUT



SETTING UP POP-UP GAZEBO INTRODUCTION


IMPORTANT! MUST READ! Please note damage due to incorrect assembly may not be covered by warranty!




A. Setting up pop-up gazebo introduction



1. You will need someone to give you a hand for proper assembly.




1. Place the center pole on the frame.
2. Gently pull the frame apart until halfway extended.



Attach the canopy with the velcro straps by matching the frame corners.

NOTE:

1. First match the canopy top to the center pole, then match the frame corners.
2. Do not pull the canopy corners down too far as this may prevent your gazebo from standing.




4. Hold onto the cross bars and open the frame until it is fully extended.

NOTE:

1. The canopy shall be attached on the frame already.
2. Gently pushing the cross bars up would be helpful when extending the frame.



5. Push the cross bars up until it locks.



6. Step onto the foot pads and lift the legs up carefully until the locks click.

B. Disassembly of your Gazebo

1. Lower your gazebo by releasing the lock on your gazebo legs.
2. Undo the canopy velcor fasteners. Please note, failure to do so may result in either bent struts or tears where the velcro is attached.
3. Release the lock of your cross bar.
4. Gently push your frame closer towards the center pole to loose the canopy. Please note, DO NOT push the frame with excessive force.
5. Remove the canopy carefully.
6. Fully collapse your frame.

AIR DRY your canopy before folding it, please note that storing your canopy wet folded may result in cracking of the PVC coating.